SINGER | Simple™

Model 3337

Feature	Benefit
29 Built-In Stitches	Basic, stretch and decorative stitches, including a 1-step buttonhole
1-Step Buttonhole	Consistent results every time
Built-In Needle Threader	Effortlessly thread the needle to start sewing faster
Top Drop-In Bobbin	Easy to see and easy to thread
STAYBRIGHT™ LED Light	See your sewing area clearly
Adjustable Stitch Length	Customize stitch length for various types of fabric
Heavy Duty Metal Frame	Long lasting durability
Free Arm	Provides easy access to cuffs, collars, pant hems and other smaller or difficult-to-reach areas
On-Board Storage	Accessories are conveniently stored in the removable storage compartment so they are easily accessible
FREE Accessories Included	Great basics to get you started: All-Purpose Foot, Zipper Foot, Button Sewing Foot, Buttonhole Foot, Sew Easy Foot (bonus item, may not be included in some areas), Darning Plate, Bobbins, Pack of Needles, Auxiliary Spool Pin, Seam Ripper/Lint Brush, Spool Cap, Edge Guide

SINGER | Simple™

Model 3337

Feature	Benefit
Free! SINGER® Owner's Class	Every machine purchase includes a FREE online owner's class.
	This machine is included in the ALL NEW SINGER® Sewing Assistant App available for both iOS and Android devices. Learning to sew has never been easier!

Singer, the Cameo "S" Design, Simple and StayBright are exclusive trademarks of The Singer Company Limited S.à r.l. or its Affiliates.
©2016 The Singer Company Limited S.à r.l. or its Affiliates. All rights reserved.